



YOUR OPENING HEIGHT = PANEL + 1 1/2"
YOUR OPENING WIDTH = PANEL + 1/4"



